

# How to configure the camera of the ship

## Technical FAQ



USV | Nov 2023

Make your work more efficient

## Prerequisites:

Hardware:

hip Camera, PC

Software:

SecureCRT: <https://chcnavigation.jianguoyun.com/p/DSz5QMkQwrmaCRj968YEIAA>

## Steps:

1. Confirm that the test computer is connected to the external network, and then connect one end of the network cable to the camera and the other end to the computer




Figure 1

2. Change the computer IP address to 192.168.1.10, and enter it in the browser 192.168.1.64, press Enter to enter the camera password setting interface, user name: admin, password: Admin1234, click OK, then the security problem configuration will pop up, and click Cancel;




Figure 2




Figure 3




Figure 4

3.Step 1. After entering the camera setting interface, select the configuration button at the top, select the image on the left, select the display setting, click the right video adjustment, and modify the image mode as the center:




Figure 5

4.Open the OSD setting, and the display date and display week will appear on the right side. Remove the previous V sign, mark the first line below the character overlay with a V sign, and then enter CHCNAV




Figure 6

5. Step 1. As shown in the following figure, select Configuration - Select System on the left - System Settings - Select Basic Information, and copy the camera SN for backup; Step 2. Click Configure - select Network on the left - select Advanced Configuration, select Platform Access on the right, change the platform access method to Fluorite Cloud, click Enable, verify and input CHCNAV, and confirm the verification code. Click OK after the second input, and then click Save;



Figure 7

6. Step 1: Select Configuration - Select Network - Select Basic Configuration - Select TCP/IP on the right, change the address of IPV4 to 192.168.53.64, and the default gateway of IPV4 to 192.168.53.254, and then click Save. At this time, the camera will restart automatically; Then change the IPV4 address to 192.168.53.254 on the test computer, and then log in to 192.168.53.254 on the browser to confirm that the camera IP address has been successfully modified




Figure 8

**CHC Navigation**

Shanghai Huace Navigation Technology Ltd.

CHCNAV | Smart Navigation & Geo-Spatial Technology  
Park,

577 Songying Road, 201703, Shanghai, China

Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963

Email: [sales@chcnav.com](mailto:sales@chcnav.com) | [support@chcnav.com](mailto:support@chcnav.com)

Skype: [chcnav\\_support](https://www.skype.com/people/chcnav_support)

Website: [www.chcnav.com](http://www.chcnav.com)