How to pair the boat with remote control

Prerequisites:

- Boat (GD100) with batteries
- RC & WIFI antenna
- PC

Steps:

- 1. Power on the boat and install RC &WIFI antenna on the boat.
- 2. Power off remote control





FAQ_ How to pair the boat with remote control

- Note: short press one time and long press the power button to power off the remote control. then you can see the indicator light gradually go off.
 - Connect the boat WIFI, logon the webpage: http://192.168.53.254/pc/login.html?v=4 Username: admin Password: Admin1234



4. Click 'System Setup' → 'Remote Control Settings' select 'Opening Match'.



FAQ_ How to pair the boat with remote control

192.168.53.254/pc/index.html?p: x +		-	×
🗧 🔶 🕐 🔺 Not secure 192.168.53.254/pc/index.html?param1=HC_PRODUCT_MODEL_GD100¶m2=false¶m3=true¶m4 🔍 🔅	≴ % ≣	¢	
CHCNAV	N:3305696	English	Quit
🖲 Unmanned ship Status Remote Control Settings ×			
Satellites Remote Control Settings			
X Receiver Configuration			
Data Recording remole control status : Disconnecting			
I/O Settings Remole control match Geneming Match			
System Setup			
Network Setting 1			
Rado Settings			
Bridge set			
Calibration Set			
Turn back Set			
K2N Setup			
Remote Control Settings 2			
Fimware			
Cloud Service Setting			

5. Power on the remote control

Note: short press one time and long press the power button to power up the remote control. then you can see the indicator lights gradually light on. If there is no sound that come from remote control, that mean it has successfully paired each other.

