

### Updating RS7 Firmware

1. Download latest firmware <https://igage.com/out/CHC/RS7/Firmware/index.htm>  
REMOVE THE .DAT by renaming and removing .DAT leaving the .bin
2. Install the handle/battery pack to the bottom of the RS7.
3. With the RS7 turned OFF, hook up the USB cables to the computer. It should show up on your files directory
4. Copy the BIN file onto the root directory
5. Start the RS7 by tapping the power button to get the lights to blink. Then hold power for 2 seconds to turn on. You will get lots of light blinking on the back of the RS7 (red, green, blue). Once the light goes solid blue the update should be completed.