

iG5

Static GNSS Receiver User Manual



Revision V 2021.03.23

Copyright, Control and Safety



Copyright © 2021 iGage Mapping Corporation. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of iGage Mapping Corporation.

iGage and 'iGage Mapping Corporation' are Trademarks of iGage Mapping Corporation of Salt Lake City Utah, USA.

All product and brand names mentioned in this publication are trademarks of their respective holders.

Windows is a registered trademark of Microsoft Corporation. Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

GNSS Safety Warning

The iG5 GNSS receiver tracks and utilizes signals from many space-based satellite navigation systems:

The Global Positioning System (GPS) is operated by the US Government which is solely responsible for the accuracy and maintenance of the GPS network. Accuracy can also be affected by bad satellite geometry and obstructions including buildings and tree canopy.

The GLONASS (GLObal NAavigation Sattellite System), is a satellite navigation system operated by the Russian Aerospace Defense Forces.

The Galileo System is the global navigation satellite system (GNSS) that is operated by the European Union (EU) and European Space Agency (ESA)

BeiDou Navigation Satellite System (BDS) (also known as COMPASS or BeiDou-2) is operated by CNSA (China National Space Administration.)

SBAS (Satellite Based Augmentation Services) including WAAS (USA), MSAS (Japan), EGNOS (Europe), QZSS (Asia), and GAGAN (India) may also be utilized by the iG5 for carrier-phase corrections, in addition to differential corrections.

iGage Mapping Corporation is not responsible for, nor warrants the viability of the space segment portion of the GNSS system. The user is cautioned that they alone are responsible for determining the application of the iG5 to their task at hand.

Any of the GNSS system components can fail at any time. Be prepared for down time and failures. Do not use the iG5 receiver for any critical navigation purpose.

FCC Compliance

The iG5 does not include a UHF Transmit Radio. No FCC license is required for operation of the iG5 in the United States.

FCC Notice iG5 receivers comply with the limits for a Class B digital device, pursuant to the Part 15 of the FCC rules when it is used in the Portable Mode.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID:	SY4-A2020
Model Number:	A10654430005000004
Model Name:	Geodetic GNSS Receiver
iGage Name:	I73
NGS Antenna Designation:	"IGAI73 NONE"

Table of Contents

Copyright, Control and Safety	2
GNSS Safety Warning	2
FCC Compliance.....	3
Introduction	7
Technical Specifications	8
The Really-Quick-Start Guide for Static Operation	9
Before First Use.....	9
In the Field.....	9
Office / Desktop	9
IMPORTANT! Exporting to other Programs (NOT OPUS)	11
What's in the iG5 Box?.....	12
Technical Assistance.....	13
Warranty / Service	13
Safety Information	13
Warnings and Cautions	13
Use and Care	14
Environment	14
Battery Safety and Disposal	15
Battery Warnings	15
Battery Life.....	15
Battery Charging.....	16
Radio Notices.....	16
Bluetooth Radio	17
Front Panel Operation.....	17
Pushbuttons	17
On/Off Pushbutton	17
Files Pushbutton.....	18
LED Indicators.....	18
Secret Reset Mainboard Mode	19
Recording Rate	19
Collecting Static Data	20
Downloading, Processing and Archiving Data	21
Installing the Download Tool	21
Connecting the iG5 Receiver to your Computer	22
Starting the iGx Download Tool.....	23
Downloading Data.....	23
Submitting an Occupation to OPUS	25
Setting the Receiver Type	28
Viewing the Observation Log.....	28
Trimming Occupation Files	29
Performing Quality Control.....	30
The MSS Factory Support Button	31
The Send to Factory Support Button	31
Advanced Download Settings	31
Configuring the Download Tool	31
'Base Project Folder'	32

'Archive All Projects'	33
'GPS Mounts on Drive'	34
'Minimum File Size to Transfer'	35
'Show UTC Time'	35
'Default HI'	35
'Default Agency'	36
'Default Operator'	36
'Decimate OPUS Submission to ...'	36
'Your Email'	37
'Show Advanced Settings'	37
'PPP Service'	38
Export 8.3 Filenames	38
Format Extended	39
Use Direct OU Submission	39
Utilities	40
"1. Undelete Occupations"	40
"2. HcRINEX Converter"	40
"3. Mark One File Unread"	40
"4. Mark All GPS Files Unread"	41
GPS Settings	41
GPS 'Settings' Tab	42
The 'Log' Tab	42
OPUS: What is it?	42
OPUS-RS (Rapid Static)	43
OPUS-Projects	44
OPUS Error Messages and Failures	44
Interpreting OPUS Results	45
US Survey Feet vs. International Feet, Scale Factors	46
Getting ready to use OPUS	47
Using OPUS-Projects	49
Best OPUS Practices for New and Experienced Users	51
The 'OPUS Error Message' Joke	51
#1 OPUS-RS is Dicey	51
#2 Only Some Submissions are being returned by OPUS	52
#3 OPUS-RS is Very dependent on the Number, Availability, Proximity, Distribution and Quality of nearby CORS Stations	52
#4 Daily vs. Hourly CORS Availability	54
#5 Some areas of the United States effectively ONLY have Daily Data	55
#6 Offline CORS Stations	57
#7 NGS CORS Station Quality	57
#8 GPS Suitable Locations	61
Semi-Trucks and Trains	63
Large Structures to the South	64
Huge Trees to the South	65
Huge Trees Overhead	65
Large Reflective Surfaces Nearby	66
Deep Canyons	67
Power Poles	68

#9 Optimizing Occupations in the Real-World	69
Longer Observations	69
#10 Mission Planning	69
#11 Be Procedure Smart: avoid Blunders	72
#12 Why does Modern RTK work where OPUS fails?	74
#13 Fresnel Zone Considerations	75
Conclusion	77
Connecting the iG5 to a PC or Smartphone via Wi-Fi	79
Turning the Wi-Fi ON	79
Connecting to the Wi-Fi	79
Setting the Recording Rate and Settings	81
Auto Record	83
Sample Interval	83
Advanced Recording Settings	86
Receiver Reset	88
Troubleshooting the iG5 Receiver	88
iG5 10-Pin Connector	90
iG5 Antenna Model	91
'Slant Height' to 'Vertical Height'	92
Manually Converting Heights	92
Examples	93
Warranty	94
Exclusions	95
RMA	96

Introduction

Thank you very much for choosing to purchase and use an iG5 GNSS receiver!

The iG5 features outstanding static performance and is easy-to-use with automated downloads and submissions, we know that your new receiver will be a valuable tool that quickly pays for itself.

This guide is designed to help you familiarize yourself with your new equipment and to offer basic information on the operation of NGS OPUS.

If you have questions or suggestions, don't hesitate to contact us:

iGage Mapping Corporation
1545 South 1100 East STE 1
Salt Lake City UT 84105 USA

+1-801-412-0011

email: **support@igage.com**

Your input is extremely valuable to us and we will listen to your suggestions!

Software updates and news are available from:

www.iGGPS.com

Click on 'Tools' for firmware, FAQs and other iG5 information.

Don't hesitate to call iGage for assistance deploying, using or updating your device. Remote assistance is available.

Technical Specifications

432 channel unicorecomm UM4B0
GPS/GLONASS/Galileo/BDS Tracking
GPS L1/L2/L5
GLONASS L1/L2
Galileo E1/E5a/E5b
BDS B1/B2/B3
QZSS L1/L2/L5
SBAS L1

Antenna Definition: NGS "IGAI73
NONE"

The Really-Quick-Start Guide for Static Operation

Before First Use

Please read the “Best OPUS Practices for New and Experienced Users” section of this User Manual on page 50.

It will save you time and failed jobs.

In the Field

1. Fully charge the internal battery or attach an external power source.
2. Mount the receiver over the point you want to survey. Level and measure the Instrument Height (HI), use a fixed height tripod or range pole with Hold-a-Pole if available. For best results: align the button panel to face north, double-check your bubble and the instrument height (HI.)
Record the HI, start time and point description in your field notes:
3. Push the ON/OFF button and hold it for 1-second until the lights flash. After 30 seconds the blue LED will flash once for every tracked Satellite.
4. Verify that the yellow ‘Files’ LED flashes once every 1-second as the receiver logs data.
5. Let the receiver record data for at least:

OPUS-Rapid Static:	16-minutes
OPUS-Static:	121-minutes
6. Turn the receiver off by pushing and holding the ON/OFF button for 1-second.

Office / Desktop


1. Install the download tool from the included thumbdrive or get the latest version from www.iGGPS.com.
2. Turn on the receiver, wait 10-seconds for the power LED to flash and then plug your iG5 into a USB connector on your computer.

3. If you see the Windows AutoPlay screen:




click on the red 'X' button on the upper-right corner.

If you see the Windows 10 AutoPlay screen:




just ignore it.

4. Start the iGx Download tool from your desktop, push the 'Download from GPS' button:



5. Highlight the occupation, set the Point ID, the Description and the HI; push the 'Submit to OPUS' button.




6. When prompted press OK, then Control-V (to paste the file location and name,) then press the "Enter" key on your keyboard, or click on 'Open' to set the ZIP filename.
7. You will need to manually select the correct antenna type. Click anywhere in the 'antenna' selection box:



antenna - choosing wrong may degrade your accuracy. NONE

Then in the drop-down selection box:



Enter 'IG5", wait a moment for the list to populate and then click on the 'IGAIG5 NONE' selection to choose the correct antenna model.


- Finally press the 'Upload to Rapid Static' or 'Upload to Static' button as prompted at the bottom of the screen.

IMPORTANT! Exporting to other Programs (NOT OPUS)


The files that are submitted to OPUS by the iG download tool are decimated and stripped of all satellite information except for GPS.

Again, Galileo, GLONASS and BeiDou are removed and the files are decimated to even 15-second intervals!

If you are using the iG5 occupation file in another application select the 'Configuration' tab, then choose 'Show Advanced Settings = Normal' (or Advanced).



An 'Export RINEX' button will be shown on the main 'Occupations' tab:



Use this export button to write **full rate** (not decimated), **full constellation** RINEX files for use in external applications.

RINEX generated with this export function have the correct User, Agency, HI, Antenna Type loaded into the headers.

What's in the iG5 Box?

Other than a suitable tripod or pole, iG5 receivers are sold as complete kits, ready to record OPUS compatible static raw data sets.

Each receiver kit includes these items:

<p>A Hard-Shell Carry Case</p> 	<p>iG5 GNSS Head</p> 
<p>Data Cable: Type-C to Type-A USB and External Power / Charger supply.</p> 	<p>The iG Download tool on a thumbdrive:</p>  <p>This User Manual</p> 

Technical Assistance

If you have questions or issues with your receiver, support is provided by iGage Mapping Corporation in Salt Lake City Utah:



iGage Mapping Corporation

www.iGage.com

1545 South 1100 East STE 1

Salt Lake City UTAH 84105

+1-801-412-0011 support@igage.com

Warranty / Service

Please see the full warranty at the end of this manual for details.

While advanced replacement programs are available, for mission critical applications we recommend purchasing Hot Spares.

Service is provided by iGage Mapping Corporation in Salt Lake City Utah.

Safety Information

This manual describes the iG5 GNSS Receiver. Before you use your receiver, please make sure that you read and understand these warnings and safety requirements.

Warnings and Cautions

An absence of specific alerts does not mean that there are no safety risks involved. Warning and Caution information is intended to minimize the risk of personal injury and/or damage to the equipment.

Use and Care

The iG5 receiver is a field ready instrument; however, it is also a delicate electronic instrument. Take suitable care to avoid damage to the instrument.

Avoid dropping the receiver as it can change the phase center of the antenna.

Avoid storing the receiver at excessive temperatures (hot or cold) as it will damage the internal batteries.

Avoid storing the receiver at temperatures less than -20° F (-29° C) and temperatures higher than 160°F (72°C) as it will permanently reduce the battery capacity and life

Environment



GNSS receivers and especially the Lithium-Ion batteries contained in them are like puppies: in the summer if you leave them in your vehicle with the windows rolled up, you will kill them.

DO NOT leave the iG5 or accessories inside a vehicle in the summer. Temperatures higher than 160°F will permanently reduce battery capacity and battery life.

The receiver is suitable for use and tested in a human appropriate atmosphere, it is not suitable for use in explosive environments.

Risk of Electrocution: Because of risk of electrocution it is very dangerous to use poles or extensions in the vicinity of overhead electrical lines. Maintain a safe distance from overhead electrical delivery systems.

If the receiver is used on a pole during an electrical storm there is a very high risk of being struck by lightning. Do not

use the product during a thunderstorm. Lay the pole down on the ground and get away from it.

Battery Safety and Disposal

The internal batteries are lithium-ion type cells. When they wear out, the receiver must be returned to iGage for replacement.

Battery Warnings

WARNING - Do not damage the rechargeable Lithium-ion battery. A damaged battery can cause an explosion or fire, and can result in personal injury and property damage.

To prevent injury or damage:

- Do not expose the receiver to fire, high temperature, or direct sunlight.

- Do not store the receiver inside a vehicle during hot weather.

WARNING - Avoid contact with the rechargeable Lithium-ion battery if it appears to be leaking. The battery fluid is extremely corrosive, and contact with it will result in personal injury and/or property damage.

If battery fluid gets into your eyes, immediately rinse your eyes with clean water and seek medical attention. Do not rub your eyes!

If battery fluid gets onto your skin or clothing, immediately use clean water to wash off the battery fluid.

Battery Life

A large internal Lithium-Ion battery is installed in the receiver. It is not user serviceable. The expected runtime is 12- to 14-hours at normal temperatures.

For shipping regulation compliance, batteries are nearly fully discharged when the receiver is shipped to you. You will need to charge the receiver before first use.

If you plan on running the receiver in static mode for longer than 12-hours, it is suggested that attach an external battery pack.

The Anker PowerCore 10000 (approximately \$20 on Amazon) style battery is a good choice and will extend receiver operation for a full day.



Larger external batteries will extend operation for even longer periods.

Battery Charging

When connected to the supplied charger with the receiver turned off, at normal temperatures, the receiver will charge about 40% per hour, to 80% and then taper to a full charge after another hour.

When the receiver is turned on the charging rate is slower and the receiver may not charge past 95%.

When the receiver is plugged into a computer instead of the supplied charger, the charging rate may be slower.

Radio Notices

FCC Notice: iG5 GNSS receivers comply with the limits for a Class B digital device, pursuant to the Part 15 of the FCC rules when it is used in the Portable Mode.

Operation is subject to the following two conditions:

- This device may not cause harmful interference
- this device must accept any interference received, including interference that may cause undesired operation

FCC Compliance:


Function	FCC-ID	Module Type
Model iG5 Device i73	SY4-A2020	Assembly

Bluetooth Radio

Radiated output power from the internal Bluetooth radio is far below FCC radio frequency exposure limits. The Bluetooth radio operates within guidelines for radio frequency safety standards and recommendations, which reflect the consensus of the scientific community.

The level of energy emitted is far less than the electromagnetic energy emitted by wireless devices such as mobile phones. However, the use of wireless radios may be restricted in some situations or environments, such as on aircraft or near blasting areas.

Front Panel Operation



Pushbuttons

The receiver's front panel has two pushbuttons **Power** and **Record**.

On/Off Pushbutton

Press the **Power** button (right-hand) for 3-seconds and release to turn the receiver ON.

If the receiver is ON, press the **Power** button for 3-seconds to turn the receiver OFF.

When the receiver turns on, all four LED's will light for ½ second.

Files Pushbutton

iG5 receivers are factory configured to automatically begin recording after the receiver is turned on and tracking satellites. (You probably won't ever need to use the **Files** button.)

If the receiver is recording data, pressing and holding the **Files** button on the left-hand-side for 10-seconds toggles the receiver from collecting data, to not collecting data and closes the current occupation file. The **yellow Files** LED will stop flashing when recording stops.

When the receiver is not recording, pressing and holding the record button for 10-seconds will open a new observation file and begin collecting observation data.

LED Indicators

There are four LED indicators on the receiver:

Power ()

Red

Power is ON. External power is not connected.

Amber

The internal battery is charging.

Green

Internal battery is fully charged.

SV's (Satellite Count)

Blue

Blinks once for each tracked satellite, waits 5-seconds, repeats. If no satellites are tracked, will blink once every 5-seconds.

Serial

Amber

Blinks amber when the receiver is not fixed and correction data received.

Green

Blinks green when the receiver is fixed and correction data is received.

Files

Amber

Blinks each time a data epoch is stored to a static file.

Push and hold the Files button for 10-seconds to toggle data recording ON and OFF.

The LED blinks when recording is active.

Secret Reset Mainboard Mode

With the receiver turned ON, push and hold the **Files** button while clicking the **Power** button 5-times. This will initialize the OEM receiver engine.

Recording Rate

The iG5 receiver is configured to automatically record raw files with a 1 Hz rate.

The receiver has 6,741,970,900 bytes available for user observation files. The receiver will generate approximately 14 MB per hour with normal constellations at 1Hz so approximately 481 hours (20 24-hour days) of continuous data can be stored on the receiver.

If you need to store data longer without downloading, you can set the recording rate to 5-seconds or 30-seconds.

The receiver is set to automatically delete the oldest file (Ring Buffer) as needed to record new files which will overwrite the oldest files on the receiver.

Collecting Static Data

OPUS-Static, OPUS-RS and OPUS-Projects

Additional information on OPUS-Static and OPUS-Rapid Static can be found in the 'OPUS' section of this manual.

Please read the "**Best OPUS Practices for New and Experienced Users**" section of this User Manual on page 50. It will save you time and failed jobs.

Prior to using the receiver, fully charge the battery to ensure that the static occupation is not interrupted by power failure.

When fully charged will run the receiver for about 12 hours at 60 degrees F.

When making occupations longer than 8-hours, or at low temperatures, you should provide external power to the receiver.

1. Place a freshly charged battery into the receiver.
2. Place the receiver above the point you want to survey.
3. Rotate the receiver so the pushbutton panel faces the North.
4. Level the receiver.
5. Record the 'Vertical Height' from the top of the survey mark to the bottom of the receiver; alternatively, you may measure a 'Slant Height' to the bottom of the blue rubber gasket at the minimum side radius.
6. At a minimum, make a careful note of the following items in your field book:


Start Time and Date

Instrument Height (HI)

PID (Point ID, Mark Name)

Description

7. Turn on the receiver. After 30 to 90-seconds, check that 5 or more satellites are tracked (the blue LED will blink 5 or more times.) The amber "Files" LED will begin to flash



once every epoch (default 1-second) as the receiver records observables.

8. Wait an appropriate time period for data collection:

OPUS-RS (Rapid Static)

Minimum of 15-minutes

Maximum of 2-hours

OPUS-STATIC

Minimum of 2-hours

Maximum 48-hours

4-hours suggested minimum

Remember that for OPUS the data is going to be decimated to 30-second intervals. It is best to wait at least 1-minute longer than required to insure that the decimation process does not leave your file too short.

9. At the end of the occupation Press and hold the ON/OFF key for one-second until the receiver closes the current file and turns off.
10. Make a note of the end time in your field book.

Downloading, Processing and Archiving Data

Your iG5 GNSS receiver includes a download, preprocessing and archive tool called

iGx Download

for use with the NGS OPUS, RTX, AUSPOS and IBGE online products. This tool runs on Windows PC's and distributed on a thumbdrive included with the receiver and is also available by web download.

Installing the Download Tool

Insert the thumbdrive in your computer and run the setup.exe file.

You can also download the latest version of the tool from:

click on the 'iGx-Download' tool link to get the latest program version.

Follow the on-screen instructions to install the download tool and support tools on your computer.

Connecting the iG5 Receiver to your Computer

Summary: Turn on the GPS, wait for 60-seconds; plug in the USB Cable to your computer.

The iG5 receiver mounts just like a USB thumb drive (flash drive) on your Windows computer. No special drivers are required.

To download data from your receiver:

1. Turn on the GPS receiver
2. Wait 60 seconds for the iG5 receiver to fully boot.
3. Plug the USB-C connector into the USB-C hole on your iG5 receiver:




and a USB port on your computer.

4. If you see the Windows AutoPlay screen:



click on the red 'X' button on the upper-right corner.

If you see the Windows 10 AutoPlay screen:



just ignore it.

The first time you attach a receiver, you may need to wait for a few minutes for standard device drivers to be downloaded / installed.

Since the drive connects as a standard USB thumbdrive the drivers are built into Windows XP, Windows Vista, Windows 7, Windows 8 and Windows 10.

If your iG5 receiver does not mount or an error message is displayed, you can usually unplug the receiver, wait a moment, then plug it back in.

If you continue to have problems check the 'Troubleshooting...' section at the end of this manual.


Starting the iGx Download Tool

You can start the iGx download tool by clicking on the iGx shortcut on your desktop:




Downloading Data

Assuming the iG5 receiver is plugged in and has mounted (as a lettered drive) just press:



The program will automatically switch to the '_New' project and download every new file from your receiver. As files are downloaded, they are marked on the receiver as 'Downloaded' however they are not deleted from the receiver and may be manually downloaded again at a later time if needed.

As the .HCN binary files are downloaded from the receiver they are automatically converted to RINEX and added to the '_New' project and displayed in the occupation grid.



You can sort the grid by Filename, PID, Description, Operation, Agency, Start Date/Time, End Date/Time and Length by clicking on the column header. Clicking twice on the header will reverse sort order the grid.

If you have any really short or unneeded occupations, you can select and delete them with:




<- the 'Delete Occupation' button

For each required observations, enter the values you recorded in your field book:

1. **PID** (Point ID) A unique short identifier for each marker (usually a 4 digit integer.) Only letters, numbers and the underscore are allowed in the PID. This number ends up as the first four characters of the filename submitted to OPUS and can be used to correlate occupations to OPUS solutions.
2. **Description** A longer description of the point. Note that quotes " and ' are not allowed in the description.
3. **HI** The Instrument Height which is the distance from the ground mark to the bottom of the receiver

- add 'F' to enter feet
 add 'S' to enter slant height
 add 'SF' or 'FS' to enter slant feet height
- Operator** This value gets placed in exported RINEX files
 - Agency** This value gets placed in exported RINEX files. By convention this is usually less than 6 characters. A current list of official contributors can be found with this online link: https://geodesy.noaa.gov/cgi-bin/get_contrib2.prl. If you plan to contribute to NGS or international projects follow this link: <https://geodesy.noaa.gov/FGCS/BlueBook/annexc/annexc.index.shtml> for information on obtaining an agency code.

If the '_New' folder gets too full, you can make a new project folder (with the "+" button) and move some occupations to the new project:



Submitting an Occupation to OPUS


Once all of the new occupations have downloaded you can submit an occupation to NGS OPUS, NGS OPUS-RS, RTX, AUSPOS, IBGE or post-process them using other software / services.

Click on an occupation to select it:

Filename	PTID	Desc	Operator	Agency	Date	Start Time	End Time
018197_13_078_A6				IMC	Monday 3/18/2013	4:13:42 PM	4:36:12 PM
018197_13_078_A7				IMC	Monday 3/18/2013	4:36:47 PM	5:04:24 PM
018197_13_079_A1	1001			IMC	Tuesday 3/19/2013	4:03:42 PM	8:19:07 AM

Occupation File '018197_13_079_A1'
 Point ID: 1001 Operator: Move Occupation to Project


Click on the 'Submit to OPUS' button:



The currently selected occupation will be processed and prepared for upload to OPUS:


1. the file is decimated to 15-second epochs, header information is stuffed
2. the file is run through TEQC to insure it will be acceptable to OPUS
3. an Observation file and a Navigation file are generated
4. the Observation file is compressed into a ZIP file

If the 'Show Advanced Settings' is set to "Simple" then the program will skip directly to the **'Verify Filename to Upload'** screen (shown below.) If 'Show Advanced Settings' is set to "Normal", "Support OPUS-Projects" or "Advanced" then this 'RINEX Solution' helper screen is shown:




The program will suggest which service (OPUS-Static or OPUS-RS) and list the time since the end of the occupation with notes about the observation.

You can click the 'Submit to OPUS' button:




to automatically open an internet browser, which will load the NGS OPUS Submission form. After the web page has loaded, the program will automatically fill in the 'Antenna Type', the 'Antenna Height' and the 'Email address.'

Next the program will prompt you with instructions for automatically entering the Zipped observation file name into the browse dialog:




Click OK and then 'Choose File to Upload' will be displayed:




Press Control-V, then the 'Enter' key on your keyboard. You may also press Control-V, then click the 'Close' button with your mouse.

You will need to manually select the correct antenna type. Click anywhere in the 'antenna' selection box:




In the drop-down selection box:




Enter 'IG5' and then click on the 'IGAIG5 NONE' selection to choose the correct antenna model.

The NGS OPUS Submission form will be ready to submit, check the entries and any extended options that you might want to use. The status bar will prompt you with the correct submission button:




Press either the 'Upload to Rapid-Static' or 'Upload to Static' button as directed and your occupation will be uploaded to OPUS for processing.


Note, you may select an alternative PPP Service provider (on the configuration tab.) Some of the alternative providers are:



Trimble's RTX Service



AUSPOS



Brazilian Institute of
Geography and Statistics

Setting the Receiver Type

(Hidden when Simple)

When files are downloaded from the receiver, the receiver type is associated with the .HCN file. The 'Receiver Model' shows an occupation's associated hardware type:

Receiver Model

If this is consistently incorrect, you can modify the device type while the receiver is connected on the 'Configuration' tab.

Viewing the Observation Log


(Hidden when Simple)

A detailed log is automatically kept for the files that you download and submit for processing.

Pressing the 'Log'



button shows the log file for the currently selected observation:



Pressing the 'Append'



button adds a date/time stamp and opens the log for user editing.

Press 'Save' to store your changes or 'Close' to close without saving.

Trimming Occupation Files

(Hidden when Simple)




Sometimes you may want to trim the start or end of an occupation file before you submit it to OPUS.

Common reasons for wanting to do this include:

- Receiver is turned on while sitting on your tailgate and then moved 20 feet and spun onto the tripod. The first 5-minutes of the observation are bogus.
- The operator forgets to turn off the receiver and observation data is collected while the receiver is transported back to the truck. The last 2 minutes of the observation file are bogus.
- The observation extends 5-minutes past midnight UTC, you don't want to wait an extra day to process. Trim 6 minutes from the end of the file.

Clicking the '?' button to the right of the trim dialog displays helpful instructions:



Note: the trimmed length is not reflected in subsequent screens or on the occupation grid. Only the submitted file is trimmed, all of the original data remains in the occupation. The trim settings must be reloaded after each submission.


Performing Quality Control

(Hidden when Simple)

Pressing the



button will launch the UNAVCO TEQC tool and run a standard RINEX QC run on the currently selected observation file. When the run is complete, the results will be shown in a window:



You can press the 'TEQC Help' button to download the User Guide for TEQC from the UNAVCO web site.

TEQC is a great tool for evaluating both the receiver's performance and the site suitability for collected data.

We use this QC function to verify receiver operation in our hardware validation process.

The MSS Factory Support Button



If you contact iGage for support, the technician may ask to view your computer screen remotely. Clicking the MSS button will download a support tool and provide a passcode that you can read to the technician who will then be able to view your screen and assist with issues.

The Send to Factory Support Button




An iGage support technician may ask you to send a troublesome occupation to the factory for assistance. Simply highlight the occupation in the grid, click the 'Send' button and the occupation with all of the support files and settings will be bundled into a single ZIP file and pushed to the factory.

After you send a file, the resulting filename will be shown. You need to let the factory support person know what the filename is so they can find it on our servers.

Advanced Download Settings

Configuring the Download Tool


Click on the 'Configuration':



At a minimum enter these values:

- Agency** your company name
- Operator** the name of the default operator
- Email** your email address

If you change 'Show Advanced Settings' from 'Simple' to 'Normal', 'Support OPUS Projects' or 'Advanced' additional setup values are shown:



You can change the rest of the configuration values as needed. Here are detailed descriptions for each of them:

'Base Project Folder'

(Hidden when Simple)

Base Project Folder

This is the full Window's path to the base folder where all of the data is stored. The default location is in your 'Documents' folder in a folder named 'iGx_Projects'. (If you have previously used the X9x download tool the default location may be 'X90-OPUS'.)

Double-click over the current path to change the folder location.

In the Base Folder, the download tool will create a sub-folder for each Project that you add. In addition there are always three special folders:

- _New** new occupation files downloaded from the receiver are placed here first
- _Deleted** if you delete an occupation, it is not really deleted, just moved to the _Deleted folder. An undelete function is included in Utilities.
- _Error** sometimes short occupations won't include navigation records, these short files end up here.

'Archive All Projects'

(Hidden when Simple)



Pressing the 'Archive' button to the right of the Base Project Folder entry will backup every occupation in every project to a single ZIP file.

This is handy if you want to move all of your data to another computer or make regular disaster recovery backups.

There are similar Archive buttons on the main page: one archives the current occupation and the other archives the entire current project.

The download tool does not provide a method to restore these backups, however they are standard ZIP files and the

Windows operating system does include a tool to decompress them.

'GPS Mounts on Drive'

GPS Mounts on Drive

This is the drive letter that the GPS receiver was last found on. Don't worry if the drive letter changes, the program will automatically find the receiver when you download data.

If you want to verify that the GPS receiver is connected and has successfully mounted as a drive, press 'Find GPS'.


Note: If you manually delete every single file and folder on the GPS receiver, the program won't be able to automatically find the receiver until after the GPS has recorded at least one file.

'Update GPS Model'

(Shown only when Advanced selected.)

The GPS Model is written into the receiver at the factory. If you delete ALL of the files on the receiver or format the receiver (it is a standard flash drive) it is possible that it will lose its receiver type.

With the receiver attached to your computer with the USB cable, click on the 'Update GPS Model' button to display this dialog:



Use the drop down 'Receiver Model' to change the receiver type.

If the HCN Key has been lost, you will find it on a white sticker inside the battery compartment.

If the HCN Key has been correctly entered, the 'OK' will be shown in a green box, otherwise it will display '????' in a red box.

Click the 'OK' button to store the receiver type and HCN key on both the receiver and your computer.

'Minimum File Size to Transfer'

(Hidden when Simple)

Minimum File Size to Transfer bytes

Every time you turn on the GPS receiver, it will attempt to track satellites and open a new occupation file. Often several small junk files will be created that don't have any meaningful data and are of no value.

The download tool will automatically ignore files smaller than this minimum value. This keeps useless files from cluttering your computer.

'Show UTC Time'

Show UTC Time

When unchecked (the default,) the download tool will show the observation start and end times in your local time zone. If you check 'Show UTC Time', then the times are displayed in UTC time.

'Default HI'

Default HI (S-slant F-feet)

When you download an occupation from the receiver, this HI will be the default associated with every occupation. You can change the HI for each individual occupation later, this is just the default.

If you ALWAYS use a 2-meter range pole, then this value will always be 2.000 and you won't have to worry about HI blunders.

FEET: If you measure up in feet, you can enter the height in decimal feet and put an 'F' after the measurement. The program will automatically convert to Meters for you.

SLANT HEIGHT in Meters: If you measure a slant height, enter an 'S' after the measurement and the program will compute the vertical height for you.

SLANT HEIGHT in FEET: If you measure a slant height in feet, enter 'SF' or 'FS' after the measurement and the program will compute the vertical height in Meters for you.

Note: if you use the 'PPP Service' = 'RTX (CenterPoint)' the submitted RINEX file spoofs a 'UNKNOWN EXT NONE' and adjusts your actual HI to reflect the generic antenna L1 offset.

'Default Agency'

Default Agency

Enter your company code here. This value is placed into every RINEX file that is exported. You can override this value on a file-by-file basis.

Typically the Agency is 2 to 10 characters in length however the RINEX definition allows values up to 40 characters in length.

'Default Operator'

Default Operator

Enter the default name of the operator / observer here. This value is placed into every RINEX file that is exported. You can override this value on a file-by-file basis.

Typically the observer is 2 to 10 characters or the operator's initials, however the RINEX definition allows values up to 20 characters in length.

'Decimate OPUS Submission to ...'

(Hidden when Simple)

Decimate OPUS Submission to seconds

When you submit a file to OPUS, it is always decimated at the NGS server to 30-second epochs (recording interval = 1 point every 15 seconds.)

The default recording interval for the iG5 receiver is 1-second.

By pre-decimating the RINEX file before uploading, the file size is greatly reduced speeding transfer to the NGS. This makes the upload process much faster while having no impact on the resulting solution.


Observations submitted to RTX are not decimated, AUSPOS submissions are decimated to 15 seconds. Observations exported directly to RINEX are not decimated.

'Your Email'

Your Email

When you submit a file to OPUS, you need to provide your Email address so the OPUS processor can return a solution to you. The email address that you enter here will be automatically entered for all submissions performed by the program.

'Show Advanced Settings'

Show Advanced Settings 

This setting determines the complexity of the iGx-Download program.

Simple: *(the Default setting)*

Hides archive functions, Minimum File size, Receiver Model, Antenna Name Decimate setting, QC function, Export to RINEX button, OPUS-Projects, the GPS Settings tab and the Log tab.

Normal:

Shows everything except for OPUS-Projects, the GPS Settings and Log tab.

OPUS-Projects:

Displays the OPUS-Projects checkbox which allows automatic submission to a NGS registered project.


Advanced:

Displays the GPS Settings and Log tabs.

Typically you will never need to use the 'Advanced' functions.

'PPP Service'


(Hidden when Simple)





The iGx download tool supports several PPP (Precise Point Positioning) services.


The submit button on the main page tracks this setting and the upload strategy is adjusted to each available service.

Additional Information is available on each service on the web:

OPUS: 
<http://geodesy.noaa.gov/OPUS/>

RTX: 
<http://trimblertx.com>

AUSPOS: 
<http://www.ga.gov.au/bin/gps.pl>

IBGE: 
<http://www.ibge.gov.br/home/geociencias/geodesia/ppp/default.shtm>

Export 8.3 Filenames

(Hidden when Simple)

Export 8.3 Filenames

If this box is unchecked then the iGx download program submits files using filenames like this:

917226_14_072_A0.OBS

The device serial number, the year, the Julian day of year and the observation number are included in the filename.

Checking this box results in exported filenames like:

10050720.14O

Where 1005 is the Point ID, 072 is the Julian date, 0 is the observation number, 14 is the year and O indicates an observation file.

Because OPUS includes the filename in the generated report, we recommend that you check the 'Export 8.3 Filenames' option.

Format Extended

(Only shown when PPP Service = OPUS)

Format Extended

The NGS returns three styles of reports:

Standard: Single Page Report

Extended: Standard + baseline details + State Plane in (s)Ft

Standard + XML: Single Page + XML

For new OPUS users, the 'Format Extended' includes one important addition: State Plane coordinates are shown in both Meters and US Survey Feet (or International Feet) at the bottom of the report. We recommend keeping 'Extended' checked by default for this reason.

Prior to submitting an OPUS report, you can modify any of the Option settings, checking this box results in the extended output initially being checked.

We recommend that you check the 'Format Extended' box.

Use Direct OU Submission

Use Direct OU Submission


Checking this box allows the program to skip displaying the NGS submission web page. All information is uploaded automatically without operation assistance.

If you use direct submission then you will not be able to specify CORS stations to include and exclude. OPUS Projects and extended outputs are supported.

We recommend that you disable the 'Use Direct OU Submission' checkbox.

Utilities

(Hidden when Simple)



Additional utilities for working with observations are included.

“1. Undelete Occupations”

When you delete an observation, it is actually moved to a special “_Deleted” folder.

Clicking the **Undelete Occupation** button allows you to specify a deleted observation to restore. When an occupation is undeleted, it is always returned to the _New project folder.

“2. HcRINEX Converter”

Files are stored on the receiver in a .HCN binary file. When the iGx download tool downloads a file, it is automatically converted to standard RINEX using the CHCData tool.

Clicking this button runs the CHCData tool in manual mode. You can browse for HCN files and manually convert them to standard RINEX files. Results are always placed in a subfolder named 'RINEX' under the file to be converted.

“3. Mark One File Unread”

When files are downloaded from the receiver, they are not deleted from the receiver. The filename on the receiver is modified to begin with an underscore ‘_’.

This function allows you to specify a single file to mark as 'unread.' Once a file is unread the next download action will re-download and convert the file.


“4. Mark All GPS Files Unread”

This function marks EVERY observation file on the receiver as unread. The next download will read every single file on the receiver. (This will take quite a bit of time if your receiver had hundreds of files.)


GPS Settings

(Hidden when Simple)

To modify the 'GPS Settings' or view the log, select the 'Configuration' tab, then choose 'Show Advanced Settings = Advanced.'




When 'Advanced' is selected, two additional tabs will be displayed:



GPS 'Settings' Tab

The GPS Settings options on the download tool are not compatible with the iG5. You can use the Wi-Fi connection to make recording interval changes to the iG5 or LandStar7 can be used via the Bluetooth interface.

The 'Log' Tab



The 'Log' tab shows detailed results of the current program operation. It may be useful to debug some aspect of file processing.

OPUS: What is it?

OPUS (Online Positioning User Service) is a free service provided by the NGS (National Geodetic Survey.)

From the NGS Website:

“This Online Positioning User Service (OPUS) provides simplified access to high-accuracy National Spatial Reference System (NSRS) coordinates. Upload a GPS data file collected with a survey-grade receiver and obtain an NSRS position via email.


OPUS requires minimal user input and uses software which computes coordinates for NGS' Continuously Operating Reference Station (CORS) network. The resulting positions are accurate and consistent with other National Spatial Reference System users.”

Here are links to more detailed information:

<http://geodesy.noaa.gov/INFO/OnePagers/OPUSOnePager.pdf>
<http://geodesy.noaa.gov/OPUS/about.jsp>

One of the most important contributions to vertical accuracy computed by OPUS is the length of occupation. Longer times are better. If you are concerned about elevation, please

remember that a 2-hour OPUS static observation has an expected height accuracy of 2.5 cm. A 6-hour occupation has an expected accuracy of 1.5 cm.



OPUS-RS (Rapid Static)


Standard OPUS-Static sessions require 2-hour observations. OPUS-RS sessions can be as short as 15-minutes.

OPUS-RS solutions are not available universally. In general, OPUS-RS requires:

- 3 (or more) CORS within 250 km of your site
- your site must be within 50 km of the polygon formed by the CORS sites

If you are working in Southwest Nevada, along the high line of Montana or in North or South Dakota, OPUS-RS probably will not work and you will have to collect at least 2-hours of data for submission to OPUS-STATIC.

Prior to collecting data for OPUS-RS you can check the latest status map to insure that OPUS-RS will work. The online OPUS-RS resource:



http://geodesy.noaa.gov/OPUS/Plots/Gmap/OPUSRS_sigmap.shtml

is updated routinely and reflects the probability that an occupation at a given location will be successful and predicts a best case accuracy for a 15-minute or 1-hour occupation.

In some areas there is a risk that if a single CORS site is unavailable, your OPUS-RS job will not be processed.

25% of all submitted OPUS-RS occupations fail. Please read the “Best OPUS Practices for New and Experienced Users” section of this User Manual on page 50. It will save you time and failed jobs.

OPUS-Projects

OPUS Projects is a relatively new online tool. Its use requires taking a NGS training class. OPUS-Projects will allow you to combine the observation files from multiple receivers and multiple sessions.

There is an excellent article and video describing OPUS Projects in the October 2013 ‘American Surveyor’ magazine. Search for “OPUS-Projects: The Next Revolution in GPS” to find a full resolution PDF.

OPUS Error Messages and Failures

There are lots of possible error messages when processing OPUS solutions. It is our experience that almost all errors fall into a single category:

“There is not enough nearby CORS data to effectively process your occupation...**yet.**”

In general, the resolution is nearly always the same:

“Wait until more data becomes available and resubmit your job.”

If you are processing OPUS-RS jobs in an area with very few CORS stations, and one CORS station was offline, waiting may not help as more data may never become available. OPUS-Static is the solution for locations where OPUS-RS is not dependable.

Interpreting OPUS Results

When you receive an OPUS solution by email from the NGS if formatted using a fixed space font it will look like this:

```
USER: testbench@igage.com      DATE: May 06, 2014
RINEX FILE: p4490900.14o      TIME: 16:08:35 UTC

SOFTWARE: page5 1209.04 master93.pl 022814
START: 2014/03/31 00:00:00
EPHEMERIS: igs17861.eph [precise] STOP: 2014/03/31 23:59:00
NAV FILE: brdc0900.14n      OBS USED: 45735 / 47174 :97%
ANT NAME: TRM29659.00      SCIT
# FIXED AMB: 162 / 171 :95%
ARP HEIGHT: 0.0083      OVERALL RMS: 0.011 (m)

REF FRAME: NAD_83(2011) (EPOCH:2010.0000)
IGS08 (EPOCH:2014.2452)

X: -2184137.494 (m) 0.003 (m) -2184138.362 (m) 0.003 (m)
Y: -3839941.381 (m) 0.001 (m) -3839940.177 (m) 0.001 (m)
Z: 4585410.516 (m) 0.005 (m) 4585410.529 (m) 0.005 (m)

LAT: 46 15 35.23578 0.005 (m) 46 15 35.25052 0.005 (m)
E LON: 240 22 8.47069 0.002 (m) 240 22 8.40767 0.002 (m)
W LON: 119 37 51.52931 0.002 (m) 119 37 51.59233 0.002 (m)
EL HGT: 208.861 (m) 0.003 (m) 208.444 (m) 0.003 (m)
ORTHO HGT: 230.163 (m) 0.018 (m)
[NAVD88 (Computed using GEOID12A)]

UTM COORDINATES      STATE PLANE COORDINATES
UTM (Zone 11)      SPC (4602 WA S)
Northing (Y) [meters] 5126276.950      103343.987
Easting (X) [meters] 297235.684      566995.383
Convergence [degrees] -1.90148112      0.63125220
Point Scale 1.00010542      0.99993063
Combined Factor 1.00007268      0.99989789
```

The most important indicators of the quality of an OPUS solution are highlighted in **yellow**.

Here are some general rules to help judge the quality of a solution:

> 90% observations used or > 80% # Fixed Ambiguities
> 50% Fixed Ambiguities or > 95% observations used
Overall RMS < 0.030(m)
Both Lat and Lon Peak-to-Peak < 0.030(m)
Ellipsoid Height Peak-to-Peak < 0.040(m)

If you collect data under canopy or in an area where there are buildings or trees that obstruct the view above 10° elevation, the number of observations used will be lower.

Make sure you use the left-hand column (NAD_83) results, not the right-hand column (IGS08) unless you know you want IGS framed results.

Be careful with heights. Both **ellipsoid** and **orthometric** heights are listed. The orthometric height is NAVD88 GPS derived and typically is the elevation you need.

The Peak-to-Peak error estimate for the orthometric height includes the error estimate for the GEOID in addition to the Peak-to-Peak error estimate value for the ellipsoid height.

US Survey Feet vs. International Feet, Scale Factors

IMPORTANT: The state plane coordinates are listed at the bottom in the right-hand column. They are in Meters. If you need Feet, you can convert them, however be careful to convert to International Feet or U.S. Survey Feet as required by your State and application:

US Survey Feet	= Meters * (3937/1200)
International Feet	= Meters / 0.3048

The misapplication of Ft/M scale factor can result in a 30 foot coordinate blunder! If you request an 'Extended Format' OPUS results, the state plane coordinates are computed and returned at the bottom of the report in the nominal foot type for the area .

If your survey is at a significant elevation (> 100 feet) you may need to apply the Combined Factor (listed on the OPUS report for both UTM and State Plane Coordinates) to inverted distances to match optical shots made at ground level.

Getting ready to use OPUS


OPUS is a great tool for grounding your survey. But OPUS is part of a larger toolset. Before you begin a project take a moment to think about the 'Big Picture':

- A. What are your GOALS?
 - a. Required accuracy
 - b. Horizontal and Vertical Datum; Geoid model choice
 - c. Survey style: OPUS-Static, OPUS-Rapid Static, OPUS-Projects
 - d. Consider FGDC Standards:


<http://www.fgdc.gov/standards/projects/FGDC-standards-projects/accuracy>

- B. Are there passive marks available for control?
 - a. Will CORS, passive or a combination control the survey?
 - b. Are local passive marks recoverable, undisturbed, sufficient quality, stable and GPS friendly?
 - c. Where are the nearby NGS CORS stations? This will determine 'Rapid Static' or 'Static' availability.
- C. OPUS-Rapid Static Requirements
 - a. Find the closest 9 CORS sites with available observations
 - b. A minimum of 3 CORS stations within 250 KM are required.
 - c. Your site must be within 50 km of a polygon created by the remaining available CORS.
 - d. If the eligible CORS count is low, check the past reliability of recent observations to insure that there is a high probability of sufficient sites for OPUS-RS to compute a solution. Use the CORS 'Data Availability' to

check for recent observations:



- D. Mission Planning: Satellite Availability and Network Planning
- How many receivers will you use for simultaneous observations? If you are using OPUS-Projects then More = Better.
 - Checkout online 'Mission Planning' tools for U.S. satellite availability using reasonable masks (>15 degrees) during collection periods. If there are any periods with fewer than 6 SV's or PDOPs higher than 3, plan on occupying points longer.
- E. How long will you observe a site? Again:




- F. Are your sites GPS compatible? Are there obstructions higher than 10 degrees?

Using OPUS-Projects

If you are contributing occupations to a registered OPUS-Project, the iGx tool can assist you when uploading files into your project by automatically entering the NGS project ID:

1. Turn ON OPUS-Projects support. On the 'Configuration' tab, set 'Show Advanced Settings' to "Support OPUS-Projects" or "Advanced":




Decimate OPUS Submission to 30.0 seconds

Your Email ms@igage.com

Show Advanced Settings **Support OPUS-Projects**

2. Add the NGS registered OPUS-Projects 'Project Identifier' supplied by your project administrator:


Click the "+" button



Move Occupation to Project

CONTROL

Enter the exact identifier




Add a New Project

Project Name MES1_I90Cooridor

as the new project name.

Select the new Project




Project MES1_I90Cooridor


OPUS-Project

Desc	Operator	Agency	Date
------	----------	--------	------

and check the 'OPUS-Project' checkbox under the Project selector.

3. Now, when you submit an occupation that has been moved to the project, the upload tool will automatically press the 'OPTIONS' button on the OPUS submission form and fill in the project identifier:

 **Options** to customize your solution.

formats	<input type="text" value="standard"/>		format details	
base stations	Use: <input type="text"/>	Exclude: <input type="text"/>	Look up site IDs 	type in 4-char sit sample <i>NOTE: the auton sparingly</i>
state plane	<input type="text" value="let OPUS choose"/>		override your nat	
project identifier	<input type="text" value="MES1_I90Cooridor"/>		enter the id provi	
my profile	<input type="text"/>		customize OPI ID	

Best OPUS Practices for New and Experienced Users

After supplying OPUS targeted receivers for many years, we know that most users experience the same reoccurring problems.

The suggestions in this chapter will save you time and failures.

The ‘OPUS Error Message’ Joke

“The NGS processing engine has a big fishbowl with 500 possible error messages printed on little slips of paper. If a job fails, the OPUS processor removes the five best error messages from the fishbowl. Next the fishbowl is shaken and three to five slips are randomly pulled from the fishbowl and returned to the user.”

OPUS error reporting is getting better. Someday this joke won’t be funny anymore.


But you should remember this: ‘you are not alone.’ Every-Single-Day a substantial portion of all OPUS submissions fail and most fail with a confusing error message.

#1 OPUS-RS is Dickey

When you submit OPUS occupations, there is a graphic that shows the daily number of jobs and the daily success rate.

On most days over 25% of all submitted OPUS-RS (Rapid Static) jobs fail!

Relatively few OPUS-Static jobs fail, and most of the Static jobs that fail initially will successfully process when resubmitted the following day.



When using OPUS RS or Static longer occupations are **always** better. OPUS-Static is always more reliable than OPUS-Rapid Static.

Please remember if you are submitting 15 to 30-minute OPUS-RS occupations **they WILL fail regularly**. Don't be surprised and don't blame your receiver.


#2 Only Some Submissions are being returned by OPUS

OPUS always returns an email. Always. But missing solutions is a VERY common issue.

If you are not getting solutions or an error messages back, the missing solutions have been trapped in your email SPAM filter or you have entered your email address incorrectly on the submission form.


#3 OPUS-RS is Very dependent on the Number, Availability, Proximity, Distribution and Quality of nearby CORS Stations

The initial stage of OPUS-RS processing determines if a network of three to nine CORS stations within 250 KM of the user location can be built.



The user location is allowed to be up to 50 KM from the polygon surrounding the selected sites which allows OPUS-RS to succeed in coastal areas where there are no CORS sites offshore. However, every CORS site that is used must be within 250 KM of the user site.

If you are in Michigan:



There are a lot of CORS stations within 250 KM of everywhere. OPUS-RS is likely to always succeed, even if a few of the stations are offline, are missing data or are very noisy and must be discarded.

If you are in the middle of Utah there are very few CORS sites available on a good day:



On a bad day, if a few stations are offline or have not yet archived data then your OPUS-RS solution will fail because there are not enough stations close to your occupation.

In many areas a single offline CORS station without data will make OPUS-RS impossible.


#4 Daily vs. Hourly CORS Availability

If you click a CORS station pin on the NGS CORS map, you will get a station summary which includes an 'Availability' note.

There are two available types:



Daily



Hourly

Daily means that a full day's CORS station data is collected and then sometime after midnight UTC the data is archived and becomes available for use as CORS data. Collection is ONCE PER DAY.

Hourly means that the previous hour's data is collected and available immediately after the top of each hour. Collection is EVERY HOUR.

Hourly data is much more desirable.

For the two sites above:

P113 data is typically available at 09:03 am (UTC) on the following day.

PUC2 data is typically available 35 minutes after the top of each hour.


If your OPUS submission has sufficient nearby hourly stations, then you can probably wait 45 minutes after the top of the hour following your file collection and an OPUS submission will be successful.

However, if you are collecting data in an area where most of the stations have only **daily** availability you will have to wait a longer time before the nearby stations will be available for use.

This is especially troublesome if you acquire observation data in two separate UTC days. (In other words, your observation spans midnight UTC.)

#5 Some areas of the United States effectively ONLY have Daily Data

Consider Western Utah:



Daily Stations Red; Hourly Stations Green

If your observation is in the western part of the state there are only daily stations available.

Let's look at an example with two observations collected on the Northwest side of Utah near Wendover Nevada:



The two observations were performed Monday afternoon (the red bars). One is a section corner, the other is vertical bench mark which is only 400 feet northeast of the section corner. Both locations enjoy completely open sky – no canopy. Both observations are **exactly** three hours in length.

The first observation starts at 1:59 pm Mountain Time (20:59 UTC) and ends at 4:59 pm Mountain Time (23:59 UTC).

The second observation starts two minutes after the first at 2:01 pm Mountain Time (21:01 UTC) and ends two minutes after the first observation ends at 5:01 pm Mountain Time.

We submit both occupations to OPUS Tuesday morning, the day after we collect the observations.

OPUS returns the first solution and it looks fantastic with 98% observations used and an ellipsoid height RMS error estimate of 0.011 meters.

OPUS returns the second solution with an ominous warning 'the observation data is noisy', only 62% of the observations were used and the ellipsoid height RMS error estimate is 0.219 meters!

Q: Is the second receiver defective?

The first OPUS solution was able to use all of the nearby UNAVCO PBO CORS sites which surround Wendover Utah. Data from these sites were available in the archive at 2:35 am Mountain (09:35 UTM) on Tuesday; in this case 9 hours and 34 minutes after the end of the first occupation.

The second occupation extended one minute into Tuesday. Data from the UNAVCO PBO sites will not be available until after 2:35 am on **Wednesday**; 33 hours and 32 minutes after the end of the second occupation.


Because no other nearby CORS data is available, OPUS has used hourly files from CORS sites over 250 KM away to process the second file. These long baselines have much higher uncertainty and result in higher peak-to-peak error estimates. If we resubmit the 2nd occupation on Wednesday, it will have excellent results, similar to the first observation.

A: The receivers are identical and neither is defective.

A smart rule-of-thumb is to try to never collect observation data that spans midnight UTC. It causes additional problems a few days after collection when OPUS is forced to splice ultra-rapid and rapid orbits. It causes additional problems in a few weeks if precise orbits become available for only the 1st portion of an occupation and OPUS has to splice precise orbits for the first portion and rapid orbits for the second portion.

#6 Offline CORS Stations

Often when you look at the 'Data Availability' plot from a CORS station's information page:



You will sometimes find that several hours or an entire day's observation data is unavailable, shown as gray instead of blue.

For a station to be used in a solution, overlapping data for the ENTIRE user occupation must exist. So if you performed an observation on Julian day 117 near the station PUC2 (shown above) and were planning on having PUC2 data available, then you are out of luck.

#7 NGS CORS Station Quality

When you submit an occupation from your receiver, your receiver's recorded data is compared with the recorded data from nearby surrounding CORS stations.

OPUS assumes that all CORS data is perfect, so if a baseline solution appears to be noisy, then (obviously) your rover data must be at fault.

In other words, any high residuals in the baseline processing are the fault of the user data and are never a result of bad CORS station data. Even when the CORS station data is bad.

OPUS error messages are structured based on this assumption of highest quality CORS data and low expectations of your user data quality.

While most CORS stations are:

- sited at excellent stable locations
- have 100% open sky view above 10 degree elevation in all directions
- have top quality leveling mounts
- are bolted to stable masonry structures or well-engineered ground monuments
- have booked coordinates that are within 2 cm of their apparent actual location
- have state of the art choke ring antenna
- have short, high-quality low-loss coaxial antenna cables with dielectric filled connectors
- enjoy top of the line GNSS receivers with the latest firmware

Stuff happens and some of the CORS stations are unreliable and a few are horrible. No matter how bad a station might be, NGS CORS will collect the bad data and the OPUS engine will use the bad data and then blame your occupation for all issues.

The only effective control that a user has is the 'Exclude' box under 'Options':

Options to customize your solution.

formats: standard

formats explained

base stations: Use: Exclude: identify any CORS you will exclude from your solution separated with line break -- sample -- find site IDs


state plane: let OPUS choose

project identifier: enter the id provided by yr

my profile: customize OPUS defaults

But how can you determine if a CORS station should be excluded?


This is a great question. The best way is to click on the 'Time Series (short term)' button. Here is an example of a great station:



Time Series for P113

You also want to look at the recent 'Data Availability':


Data Availability Profile for: P113



Availability for P113


The position trends are very stable and are within 1 cm horizontal and vertical of the published IGS08 positions. The average locations and all of the error bars are fully contained in the green error bands. Coupled with continuous recent Data Availability this station appears to be a great CORS resource.

However, if you look at a station's Time Series and it looks similar to this:



You will want to ALWAYS exclude the station from your solutions. If you catch this site on a bad day (and it has a lot of them) you can expect significant elevation and horizontal errors.

Even worse sites abound in the NGS array:




These stations and all the others like them are unsuitable for any processing use. It is your responsibility to exclude them from your solutions.

#8 GPS Suitable Locations

The NGS recommends that you submit GPS occupations collected in **GPS suitable locations**. However, very little NGS guidance is provided for what is ‘GPS suitable’ in the context of OPUS submissions. Let’s compare good and bad locations.

Best Case Scenario

The best possible site would have a totally clear view of the sky above 10° at all azimuths where there is a possibility of a GPS satellite being in the sky:



Obstructions to the North not important in North America

Note: OPUS will process observations down to 10° elevation so you should set your receiver to start tracking a few degrees below 10°, or just allow it to track all the way to the horizon (0 degrees Elevation Mask.)

Attributes of a great GPS location for collection OPUS ready occupations:

- No overhead power lines
- No trees: leaves on or leaves off
- No power poles (wood or metal)
- No radar or radio paths that cross over the top of the receiver
- No chain link fences nearby
- Locations under busy landing paths are undesirable
- No large 'GPS reflective' surfaces (metal roofs) nearby: avoid multipath
- Receiver facing correct direction: usually MMI (Man-Machine-Interface AKA the push buttons), antenna connector or North fiducial pointing to the North.
- Receiver mounted very securely on well braced, fixed-height tripod

- No chance of giant birds sitting on your antenna during occupations:



This picture is an actual GIANT crow sitting on an actual CORS antenna!

- No chance of trucks higher than your antenna passing nearby during occupation

Yes, users get great results in challenging locations all the time. And you may be lucky, but these are real rules and you should consider respecting them.

Worst Case Scenarios

All of the sites presented below are actual customer sites (or in some cases slightly obfuscated locations to save embarrassment.)

Remember that during times of low DOP (see the mission planning section of this document) you may get reasonable OPUS-Static and OPUS-RS solutions at these challenging locations. Longer (3-hour) and very long occupations (over 8-hours) may be dependable because the high-DOP conditions are bridged with times of good coverage. However, in general, you should avoid the following scenarios.

Semi-Trucks and Trains


This bench mark is 3 feet north of the eastbound edge-of-pavement of I80 near Green River Wyoming:



It has fantastic views in all directions, unfortunately a semi-truck drives by every 20-seconds and completely obscures a receiver's view of the southern sky. This forces the receiver (and OPUS) to lose lock. This is a **BAD** location and will greatly increase the RMS error estimates and drop the percentage of observations used.

Large Structures to the South

This 8-story parking garage is 40 feet to the southeast of the brass rivet in the street. The red arrow points South.



This is a **bad** location because the structure completely blocks the antenna's view to the South and East.

Huge Trees to the South

BAD: This site is not suitable for GPS observation because of large trees to the south:



Southern sky is fully blocked and trees obscure view directly overhead.

We can debate:

- leaves on, leaves off
- pine needles vs. broad leaves
- length of pine needles
- size of tree-trunks
- size of branches

But trees above 10° to the East, South or West are bad and 100% canopy is really bad.

Huge Trees Overhead

Trees (with or without leaves) directly above the antenna prevent the receiver from having a clear view of the sky. Even though this location has open water to the South, it is directly underneath large trees. Water can also be a source of significant multipath (see the next section). This is a **BAD** location:



Large Reflective Surfaces Nearby

Your receiver trusts that the signals that it receives have traveled directly from the satellite to your antenna. Large nearby surfaces present opportunities for the receiver to have signals arrive having taken multiple paths (multipath) or entirely the wrong path.

Not only do these tanks block the view to the South, but they also have metal-reflective surfaces that provide a multiple length signal path for every signal from every satellite to the observation area:



(this image is looking South)


Flat metal surfaces are bad. Corrugated metal surfaces (like corrugated roofing) are even worse. Some mirrored glass windowing used on building exteriors is reflective at microwave frequencies. Box truck bodies, metal buildings, metal roofs and open water are all potential sources of multipath.

Deep Canyons

Locations at the bottom of deep canyons, especially East-West trending canyons will present full, 100% obstruction below the ridge line to the South. Most of the GPS satellites are to the South. This is **BAD**.

RBUT (below) is a NGS CORS site, and is the closest CORS site to the iGage office in Salt Lake City Utah. This site is hindered by a solid mountain 30° mask to the South. This could be a challenging location for GPS observations and is not a great location for a CORS site.

Moving further North would gain elevation, effectively lowering the southern mask.



Power Poles




< 500 KV DC

Transmission Lines and Tower

This class-1 elevation bench mark with measured gravity is unfortunately in a location that is no longer suitable for GPS observations. It was set prior to the construction of the powerline. This is a **BAD** location.

You should avoid locations that are under high voltage transmission lines and have large steel towers directly to the south.

Smaller power poles and lines are also unacceptable, especially if they are south of the occupation site:



#9 Optimizing Occupations in the Real-World

Receiver Placement

In North America, the most important sky is to the East, South and West (because there are never any GPS satellites directly north.) So, if you are setting up in a field that is surrounded by large trees, locations in the middle of the North side of the open area are preferable because the southern sky effectively opens up:



Longer Observations

OPUS-RS is especially vulnerable to bad sites. If you think a site may have problems, try to collect over two hours of data so that you will have the option of using OPUS-Static. You can always trim the 2-hour observation file and also submit it as a Rapid Static job in addition to the Static job.

A six-hour occupation may return great results at a site where 2-hour occupations fail. More-time in adverse locations is always better.


#10 Mission Planning

With modern GNSS RTK receivers that track lots of satellite constellations and lots of signals, mission planning is no

longer required. A full GNSS receiver tracks so many satellites that there are no bad times..

However, OPUS is **GPS only** and mission planning should be used to select better times to occupy sketchy locations. Especially if you are using OPUS-RS.


Here is a typical GPS Only Mission Planning example:




Lower DOP is better than higher DOP. You can see that most of the day, DOP is excellent. Most OPUS submissions will be successful. However starting at 5:30 pm there are large DOP spikes.

At this location, on this day, any one-hour OPUS-RS occupation from 5:30 pm to 9:30 pm will certainly **fail**. However a one-hour OPUS-RS occupation from 11:30 am to 12:30 pm (or most of the rest of the day) will probably be **successful**.

DOP is a function of how many and where the satellites are in the sky. We prefer more satellites, spread over a larger portion of the sky, with one or more satellites in every quadrant:



11:30 am **Great**



8:50 pm **Bad**

One pitfall of OPUS-RS is very short occupations may entirely fall into a very high-DOP period. As you can see from the DOP plot above, high DOPs rarely last for more than an hour and longer OPUS-Static occupations will usually have some periods of low DOP and excellent coverage.

The change in satellite constellation, which determines PDOP is why a receiver will work one day and then not work in a nearby location at a different time.

#11 Be Procedure Smart: avoid Blunders


Assuming that your receiver is in a location that is suitable for GPS observations, at a suitable time, there are several procedural blunders that you can do to force a bad result:

- Mounting system is not level and receiver is not centered over the ground mark.
- Antenna height (HI) is wrong.
- Antenna is mis-rotated, doubling antenna compensation errors.
- Wrong antenna type is selected.
- No battery in head with external power

Use a Fixed Height Tripod, Get the HI Correct!

The #1 OPUS procedure failure is a blundered instrument height. The ONLY HI that OPUS will accept is the vertical height above ground to the ARP (Antenna Reference Point) in meters.

If you use a tribrach, you are going to have to make a slant measurement and then reduce the slant distance and SHMP (Slant Height Measurement Point) vertical offset to a metric vertical height. The process is described on page 92 in the 'Slant Height' to 'Vertical Height' section of this User Manual.



Slant reduction error is also very common source of blundered instrument height. The iGx_Download tool makes this computation automatically for you, however you must keep track of Slant vs. Vertical and Feet vs. Meters.

Transposition of digits in random heights that occur with tribrachs on tripods is a common source of error. Measurement to the wrong place on the antenna is a common source of error. Mixing slant measurements in feet with metric SHMT and radius constants is a common source of error. Confusing slant heights between multiple occupations is a common source of errors. Using 'inch' tapes instead of 'tenths' tapes is a common source of errors.

All of these errors are eliminated if you use a fixed height 2.0 meter tripod or a 2-meter pole with a Hold-a-Pole for every static occupation. The answer is always just “2.0” meters. Which is very easy to remember.

Rotate your Receiver Correctly

Every antenna has a ‘correct’ rotation. It is VERY important to spin the antenna so that it faces the correct direction.

You can determine the correct rotation for any modeled antenna by looking up the antenna definition on the NGS Antenna Calibration website

The iG5 should have the MMI (the button/LED panel) turned to face the North.

What happens if you don’t rotate the antenna correctly?

OPUS has a calibration file for every antenna that relates a change in L1 height offset by the position of the satellite in the sky and the XY offset of the center of the antenna from the center of the mounting nut.

OPUS compensates for the northing, easting offset assuming the antenna is facing North. If you rotate the antenna 180° so that the MMI is pointing to the South, then the offset error is doubled and your final solution will be in error by double the centering offset!

Bad rotation alignment can also be responsible for making an occupation appear noisy. OPUS compensates for the antenna vertical offset changes depending where satellites are in the sky. If you mis-rotate the antenna then the compensation will be applied incorrectly.

Use the Correct Antenna Model

Make sure that you have the correct antenna model selected. Some antenna have multiple radomes and revisions listed.

For example: the Ashtech version of the Dorne Margolin chokering (which is a replacement of ASH700936 which has even more models and revisions) has 10 revision / dome combinations:

ASH701945B_M	NONE
ASH701945B_M	SCIT
ASH701945B_M	SCIS
ASH701945B_M	SNOW
ASH701945C_M	OLGA
ASH701945C_M	SCIS
ASH701945C_M	SNOW
ASH701945C_M	SCIT
ASH701945C_M	PFAN
ASH701945C_M	NONE

Each revision has a different calibration, you must select the correct model or you will introduce substantial height uncertainty to your solution.


#12 Why does Modern RTK work where OPUS fails?

Yes, OPUS is substantially more finicky than modern GNSS RTK. OPUS jobs routinely fail in places and at times that RTK works flawlessly. There are two primary reasons: number of satellites and baseline length.


Number of Satellites and Signals

OPUS is GPS only. Modern GNSS RTK uses additional satellites (GLONASS, Galileo, BeiDou) and additional signals like GPS L2C, GPS L5 and GLONASS L3.

Compare these two sky plots (same time, same location):



GPS Only



GPS + GLONASS + Galileo + BeiDou

More satellites are better. More signals are better. Even though the iG5 tracks GPS, GLONASS, Galileo and BeiDou satellites, OPUS currently only uses the GPS observations. So a great constellation like the one on the right is reduced to the minimal constellation on the left.

A modern GNSS RTK receiver has and **uses** more signals at all times than the OPUS processing tools.

Baseline Distance

OPUS processes GPS baselines from your receiver all the way back to each individual CORS station. Typically these will be 45 KM (28 miles) to 150 KM (93 miles) baselines. In some areas the nearest CORS station might be 250 KM distant!

RTK processes the baseline from your RTK Base to your RTK Rover which typically will be less than 10 KM (6 miles.)

Short baselines 'Fix' more easily and have substantially less noise.

#13 Fresnel Zone Considerations


Most GPS users think of the radio path from their receiver to each of the satellites is like a small laser beam. This is incorrect.

The GPS beam width is spread out in a cigar shaped area known as the 'Fresnel Zone'.

Fresnel is pronounced with a silent-s: Frenel), named after French physicist Monsieur Fresnel.

Wikipedia has an excellent article on the Fresnel effect: https://en.wikipedia.org/wiki/Fresnel_zone; be sure to check out the section on 'Fresnel Zone Clearance' mid-article.

The Fresnel effect explains for why your GPS receiver will track a satellite which is fully behind a building or ridgetop. The beam width is wide enough that a portion of the signal reaches the GPS receiver, even though the beam's center is fully blocked by the building.



Tracking a satellite means that the satellite is 'visible' to your receiver, however just tracking is not sufficient to accurately evaluate a carrier-phase position.

To compute an accurate position, your receiver needs a very clean signal with few reflections, obstructions or delays. Any object blocking a part of the beam can be a source of reflection, attenuation or delay.


Clear path means that you don't just need a small opening in the trees for a laser beam to shoot through. You need an opening in the trees large enough that most of the energy which is spread out over the Fresnel beam width reaches the receiver with no obstructions.

How wide is the Fresnel beam along the path? Much wider than you think!

Here is a beam-width chart for GPS L1 (1.575 GHz):

Distance	1st Fresnel Dia
0.0	0.0
0.5	1.1
1.0	1.6
2.0	2.2
5.0	3.5
10.0	5.0
20.0	7.1
50.0	11.2
100.0	15.8
3300000.0	6414.3

1st Fresnel Zone Radius vs. Distance From Rover



1 foot above your GNSS antenna, the beam width is 1.6' in diameter. 20 feet above the rover antenna (perhaps the midpoint of tree canopy), the 1st Fresnel beam diameter is 7 feet! A clearing in the treetops 100' above your antenna needs to be 16' in diameter.

At the midpoint between your receiver and the satellite, the Fresnel beam is over 6,000 feet in diameter! And that is for the signal for a single satellite, multiply this by the number of tracked satellites and there is signal energy everywhere.

Conclusion

There are lots of things that can go wrong with OPUS occupations. Some you can control, some you can't.

If you stack multiple problems:

Bad Constellation + Short Occupation + Moderate Canopy + Bad HI => FAILURE

Your OPUS solutions will fail or have high RMS estimates and the time you spent collecting the observation will be wasted.

The OPUS family of online tools: OPUS-Static, OPUS-RS, OPUS-Projects are amazing. They allow users to generate reliable X, Y and Height coordinates for GPS suitable locations, anywhere in the world. Hopefully by utilizing the simple rules presented in this chapter, all your jobs will be

OPUS-Successful!

Connecting the iG5 to a PC or Smartphone via Wi-Fi

The iG5 receiver has an internal Wi-Fi Access Point which can be used in conjunction with a PC or smartphone to setup and control every feature of the receiver including firmware updates.

Turning the Wi-Fi ON

Wi-Fi: IMPORTANT!

First make sure that the Wi-Fi hotspot in the iG5 is turned on. To lengthen battery life, the Wi-Fi access point in the iG5 is automatically powered off if it is not used for 15-minutes!

When the receiver is first turned-on Wi-Fi is enabled, then after 15-minutes if Wi-Fi is not in use it is automatically powered off.

Once off, click the **Files** button once, then 5-seconds later the Wi-Fi will be powered on and accessible again.

As long as a computer or phone is connected to the iG5 Wi-Fi, it will remain powered on.

Connecting to the Wi-Fi

Connect a computer to the iG5 receiver using Wi-Fi.

Device Wi-Fi Overview:


SSID:	GNSS-#####	device-serial-number
Wi-Fi Key:	12345678	the Wi-Fi Password
Address:	192.168.1.1	
port:	80	
User Name:	admin	lower case
password:	password	lower case

To connect the iG5 to your PC with Wi-Fi:




Click on the Network icon in the System Tray


1. Find the iG5 receiver, it will be named 'GNSS-' followed by the full serial number of your device:



2. Click on the receiver, then click on 'Connect':




3. Enter the Wi-Fi password "12345678"



4. Click on 'Next' to connect by Wi-Fi to the GPS head.
5. Open a browser window on your PC or phone and type in the GPS IP address:

<http://192.168.1.1>




6. A Login screen will be shown:



The **Login Account** is 'admin' and the **Password** is 'password'.

- Click the '**Login**' button, you will be at the '**Home Screen**' of the GPS receiver:



From the Wi-Fi interface, you can configure nearly every aspect of the receiver's operation using the left-hand section tabs and sub-items.


Setting the Recording Rate and Settings

Log into the iG5 using Wi-Fi as described in the previous section.

Click on **Data Recording** on the left-hand panel:




The **Log Settings** will be shown:



You can turn recording **ON** and **OFF** using the **Switch** buttons.

Clicking **Clear Data** will delete the current observation file.

Clicking **Clear All**  **Clear All** clears ALL observation files on the receiver.

To change the recording defaults, if the **Log Status** is **Recording** or **Activated** is **Yes** then click on the **Switch: OFF** button. Then click on **Modify**, the **Recording Edit** dialog will be

shown:

Recording Edit

Auto Record: Yes No

Sample Interval: 1Hz

Elevation Mask: 0 (*)

Duration Time: 1440 (Minute)

Site Name: 3327906

Antenna Height: 0.0000

Measure Way: Antenna Phase Ce

Storage Format: HCN

RINEX Version: OFF

Advanced

Save Back

The most commonly modified settings will be displayed, click on **Advanced** (see below) to change arcane settings.

Descriptions of the **Standard** and **Advanced** settings follow:

Auto Record

Set **Auto Record** to **Yes** and the receiver will always open a new file after it begins tracking SV's. The default setting is **Yes**.

You can always toggle the current setting by clicking and holding the Files button for 10-seconds.

Sample Interval

Sample Interval: 1Hz

Elevation Mask: 1Hz

Duration Time: 5s

Site Name: 15s

30s

60s

The Sample Interval controls how often data is recorded to memory. The default is 1 Hz or one epoch per second.

Each data record contains the tracking information for every tracked satellite.

OPUS only uses data on 30-second intervals (0 and 30 seconds past the top of each minute, using GPS time.) If data is post-processed in external products, like CGO2, a higher

data rate can be very advantageous. If the receiver is used as a base for UAV operation, 1 Hz data is preferred.

The receiver has 6,741,970,900 bytes available for user observation files. The receiver will generate approximately 14 MB per hour with normal constellations at 1 Hz so approximately 481 hours (20 24-hour days) of continuous data can be stored on the receiver at the default rate. Setting the rate to 30-seconds will increase the available recording time 30 X.

Elevation Mask

The **Elevation Mask** determines the elevation above the horizon where satellites will begin to be tracked. The default is 0 degrees.

The NGS recommends a minimum value of 10-degrees. It is best to allow the receiver to begin tracking satellites before they reach 10-degrees so that all tracking has stabilized.

Duration Time

The **Duration Time** sets the maximum length of a single file. The default is 1440-minutes which is 24-hours or 1-day.

OPUS will not accept a file that crosses midnight UTC twice. This limits observations to 48-hours.

It is customary to collect 24-hour file chunks and splice them together as needed for longer occupations.

Some advanced settings impact the **Duration Time**.

Site Name


The **Site Name** is included in the output file. **It is highly recommended that you leave the Site Name equal to the device serial number.** This ensures that unique filenames are always generated by multiple receivers that run at the same time.

When files are submitted to OPUS or exported by the iGage iGx_Download tool you can edit the **Point Name** and **Point Description** contained in exported files.

Antenna Height

This height is included in collected files, however the iGx_Download tool allows/forces you to overwrite this value when submitting OPUS files or exporting data. The default value is **0.0000** meters.

Measure Way




This setting indicates how the **Antenna Height** should be applied to collected files. This setting is overwritten in files exported by the iGx_Download tool so typically its setting does not matter.

Don't use **Slant Height** as the **SHMP** of the internal measurement is undefined.

Don't use **Vertical Height** as the **L1 Phase Center** height assumed by the receiver may not match the NGS calibration.

Storage Format



Storage Format controls the non-RINEX file type which is stored on the receiver. The default is **HCN**. If you plan to use the iGx_Download tool, the format **MUST BE HCN**.

OFF disables native file format storage.

HRC is a compressed **HCN** file, however is it not compatible with iGage supplied tools.

The advantage of storing **HCN** files is you can later decide to output RINEX2 or RINX3 files and you can later control included tracking. If you rely on RINEX output, you are constrained to the initial selection.

RINEX Version

RINEX Version:

You can output both HCN and RINEX files simultaneously. The default **RINEX** is **OFF** because it is possible to convert HCN to either variant of RINEX.

Remember that RINEX is larger than HCN and the storage reduces the amount of data that can be kept on a receiver.

Advanced Recording Settings

The screenshot shows the 'Recording Edit' dialog box with the following settings:

- Auto Record: Yes No
- Sample Interval: 1Hz
- Elevation Mask: 0 (*)
- Duration Time: 1440 (Minute)
- Site Name: 3327906
- Antenna Height: 0.0000
- Measure Way: Antenna Phase Ce
- Storage Format: HCN
- RINEX Version: OFF
- Advanced button
- Start Date: Yes No
- Apply Time: Yes No
- Integral Point Store: Yes No
- Circulating Memory: Yes No
- Single Observation Only: Yes No
- Store Location: Internal Storage
- Assigned Storage: 6000 (MB)
- Observer: CHC
- Observe Agency: CHC
- FTP Push: Close, 1.ftp server 1, 2.ftp server 2, 3.ftp server 3

Buttons: Save, Back

Start Date / Start Time

Start Date: Yes No
Date: 1/1/1900
Apply Time: Yes No
Start Time: 10:30 (UTC Time)

You can enable a date and time to open a recording file. The default is **No** for both settings. Since it is possible to strip occupations periods from daily files, it is usually safer to ALWAYS record data, then pull the time periods of interest.

If you choose to utilize **Start Date** and **Start Time**, they must be entered in UTC time zone and you should be very careful

to test your settings as non-overlapping data collection is very common.

Integral Point Store

Sets observed files to Kinematic in expectation of triggering occupation markers.

The default setting is **No** and you should not change this setting.

Circulating Memory

Implements a 'Ring Buffer' where the oldest occupation files are automatically deleted to make room for new files.

The default is **Yes**.

Single Observation Only

If set to **No**, at the end of the **Duration Time** the receiver will stop recording data.

The default is **Yes** and it is recommended that you not change this setting.

Store Location

It is possible to attach an external thumbdrive using an OTC cable to store observation data externally. The default setting is **Internal Storage**.

Assigned Storage

Only the Assigned Storage space is available for observation storage. When this limit is reached, if the Circulation Memory is set to Yes; the receiver will delete the oldest observation file to make room for new files as needed.

The default value **6000** (6-gigabytes) should be reasonable for all applications.


Observer and Agency

These strings are included in RINEX files. If you use HCN output files with the iGage iGx_Download tool these settings are ignored.

Receiver Reset

Once logged into the Web interface, click on **Receiver Configuration** then **Receiver Reset**. You can reset the OEM board and the receiver's settings.

The most common reset mode is **Clear Satellite Data**:



Troubleshooting the iG5 Receiver

1. Receiver won't turn on:

Internal battery is fully discharged. Plug into charger for 15-minutes and try again.

2. The receiver is not tracking satellites?

The BLUE LED flashes once for each SV (satellite vehicle) that is currently tracked.

If you are indoors and have a metal roof, the LED will flash once every second and no SV's will be tracked.

The receiver should begin tracking within 30-seconds after a warm start. After a cold start (off for more than 1 week) it may take 90-seconds for the receiver to begin tracking.

Try doing a reset on the receiver from the front panel:

Secret Reset Mainboard Mode page 19

Try clearing the receiver's satellite data:

Receiver Reset: Clear Satellite Data page 88

3. Is the receiver storing observation data?

The right-hand yellow Files LED will flash once every time data is stored to the current occupation file. The default recording rate is at 1-second interval; thus, the yellow Files LED should flash once the receiver begins tracking data.

Auto-recording is controlled via the Web Interface, accessible using Wi-Fi. See:

Sample Interval page 83

4. The RED Power LED is flashing!

If the RED Power LED is flashing, then the internal battery is very low. Connect external power or turn receiver off and replace the battery.

5. The GPS receiver won't mount as a Disk Drive.

A. Before plugging GPS cable into your PC try turning on the GPS and waiting for 20 seconds?

B. Unplug, wait 15-seconds, try again

C. Try another USB port.

D. Use an external USB Hub (this fixes intermittent disk mounts, but we don't know why.)

E. Try other computers.


F. Try turning off your PC, wait a minute and then turn on again. Reinsert the USB cable.

iG5 10-Pin Connector

The iG5 uses a standard Type-C connector for charging and data download.

USB Port Definition

The iG5 has a standard USB Type-C connector.



When connected to a computer with a USB cable, the receiver mounts as a lettered disk drive.

iG5 Antenna Model

The iG5 antenna has been modeled by the NGS as:

'IGAI73 NONE '

The calibration is available in the master antenna calibration list available from:

<https://www.ngs.noaa.gov/ANTCAL/>

Calibration Values:

L1	<i>0.08444</i>	meters
L2	<i>0.06825</i>	meters
Radius (minor)	<i>0.0597</i>	meters
SHMP	<i>0.0534</i>	meters

If you encounter an application that does not have the IGAI73 antenna model available, the antenna model:

'CHCI73 NONE '

is nearly identical and may be substituted with minimal change in computed location.

'Slant Height' to 'Vertical Height'

The iGx Download tool automatically converts from 'feet to meters' and from 'slant to vertical' using the currently selected receiver model.

If you have a vertical measurement in feet you can enter an 'F' after the measured vertical height. For the iG5:


"4.512 F" becomes
"1.375,3" meters vertical

If you have a slant height in feet you can enter a 'FS' (or 'SF') after the measured slant height:

"4.512 FS" becomes
"1.320,6" meters vertical

If you have a slant height in meters, enter an 'S' after the measured slant height:

"1.523 S" becomes
"1.468,4" meters vertical



Manually Converting Heights

v = Vertical Height


s = Slant Height

r = Receiver Radius

h = SHMP = Slant Height Measurement Point

$$v = \sqrt{s^2 - r^2} - h$$

Receiver	Radius r (meters)	SHMP h (meters)
iG5	0.05970	0.0534



Examples

Measured Slant s (feet)	Slant s (m)	iG5 Vertical v (m)
6.965	2.123	2.068,7
5.148	1.569	1.514,6

Warranty

IMC is “iGage Mapping Corporation” of Salt Lake City Utah USA.

IMC warrants the iG5 receiver to be free of defects in material and workmanship and will conform to our published specifications for these periods:

GPS receivers:	1-year
Cables and accessories:	30-days
Internal Battery:	30-days

This warranty applies only to the original purchaser of the product.

Hardware: Purchaser's exclusive remedy under this warranty shall be limited to the repair or replacement, at IMC's option, of any defective part of the receiver or accessories which are covered by this warranty. Repairs under this warranty shall only be made by IMC at an IMC service center. Any repairs by a service center not authorized by IMC will void this warranty.

In the event of a defect, IMC will at its option, repair or replace the hardware product with no charge to the purchaser for parts or labor. The repaired or replaced product will be warranted for 30-days from the date of return shipment, or for the balance of the original warranty, whichever is longer.

Software: IMC warrants that software products included with hardware products will be free from media defects for a period of 30-days from the date of shipment and will substantially conform to the then-current user documentation provided with the software. IMC's sole obligation shall be the correction or replacement of the media so that it will substantially conform to the then-current user documentation. IMC does not warrant the software will meet purchaser's requirements or that its operation will be uninterrupted, error-free or virus-free. Purchaser assumes the entire risk of using the software.

Exclusions

The following are excluded from the warranty coverage:

1. Periodic maintenance and repair or replacement of parts due to normal wear and tear.
2. Product Finishes.
3. Batteries exposed to heat, cold; or batteries opened or physically damaged.
4. Installations or defects resulting from installation.
5. Any damage caused by (i) shipping, misuse, abuse, negligence, tampering, or improper use; (ii) disasters such as fire, flood, wind, and lightning; (iii) unauthorized attachments or modification.
6. Service performed or attempted by anyone other than an authorized IMC service center.
7. That the receiver will be free from any claim for infringement of any patent, trademark, copyright or other proprietary right, including trade secrets.
8. Any damage due to accident, resulting from inaccurate satellite transmissions. Inaccurate transmissions can occur due to changes in the position, health or geometry of a satellite or modifications to the receiver that may be required due to any change in the GPS. IMC GPS receivers use GPS, GLONASS, BDS and GALILEO satellites to obtain position, velocity and time information. GPS is operated by the US government, which is solely responsible for the accuracy and maintenance of the GPS system. OPUS and OPUS-RS is a service of the NGS and IMC shall not be responsible for issues with NGS provided services.

Except as set forth in this limited warranty, all other expressed or implied fitness for any particular purpose, merchantability or non-infringement, are hereby disclaimed.

IMC shall not be liable to the purchaser or any other person for any incidental or consequential damages whatsoever, including but not limited to lost profits, damages resulting from delay or loss of use, loss of or damages arising out of breach of this warranty or any implied warranty even though

caused by negligence or other fault of IMC or negligent usage of the product.

In no event will IMC be responsible for such damages, even if IMC has been advised of the possibility of such damages.

This written warranty is the complete, final and exclusive agreement between IMC and the Purchaser.

RMA

To obtain warranty service the purchaser must obtain a return materials authorization (RMA) number prior to shipping by calling 1-801-412-0011.

Purchaser's return address and the RMA number must be clearly printed on the outside of the package. IMC reserves the right to refuse to provide free-of-charge service if the date of sale cannot be determined or if the serial number is altered or removed. IMC will not be responsible for any losses or damage to the product incurred while the product is in transit or is being shipped for repair. Insurance is recommended. IMC suggests using a traceable shipping method such as UPS, FedEx or USPS with signature tracking when returning a product for service.

NEVER INCLUDE BATTERIES in return shipments. If you ship batteries to iGage they **WILL NOT BE RETURNED TO YOU.**

The Purchaser shall always pay shipping to IMC, IMC will return warranty repairs by UPS ground, unless the Purchaser agrees to prepay expedited service costs. IMC will not pay for warranty returns to destination outside of the contiguous 48-states. The purchaser shall always pay any associated duty associated with warranty repairs.